



Dimension: 5"w x 1.6"h

V-FSN-50

WATERPROOF STAIR NOSE

Used to finish the end of a step

*Flush stair nose installation.

Surface: Wear resistant
Core Material: Rigid PVC

- 1

Install flooring 4.5" from the edge of the bull nose to the flooring (see illustration).
- 2

Measure and trim to fit.
- 3

Apply a generous bead of construction adhesive along the underside of the stair nose.
- 4

Carefully roll the stair nose into place against the front of the step, making sure the transition is in place. Once the transition is in its desired position, press down firmly over the entire stair nose, making certain the transition is in place and tight against the riser. For added security, use finishing nails.

Allow adhesive time to cure according to directions.