

**Dimension:** 1.5" w x 0.49" h

# V-EC-10

## WATERPROOF END CAP

Used to fill the gap between the floor and carpet, hearths or against sliding doors.

Used with floors ranging from 10-12mm height.

*For concrete use appropriate Rawl Plugs (Not Included)*

*Glue with construction adhesive (do not glue floor)*

**Surface:** Wear resistant

**1**

Install the flooring leaving a 1-1/4" gap between the two floor surfaces for the end cap installation.

**2**


Measure and trim to fit.

**3**

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor. (or glue down with construction adhesive).

**4**

Starting at one end, press the molding into the track inching along the length of the molding. It will NOT snap in all at once. You may also use a rubber mallet.



**Dimension:** 1.5" w x 0.25" h

# V-EC-14

## WATERPROOF END CAP

Used to fill the gap between the floor and carpet, hearths or against sliding doors.

Used with floors ranging from 2-6mm height.

*For concrete use appropriate  
Rawl Plugs (Not Included)*

*Glue with construction adhesive  
(do not glue floor)*

**Surface:** Wear resistant

**1**

Install the flooring leaving a 1-1/4" gap between the two floor surfaces for the end cap installation.

**2**


Measure and trim to fit.

**3**

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor.  
*(or glue down with construction adhesive).*

**4**

Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once. You may also use a rubber mallet.*



**Dimension:** 1.5" w x 0.43" h

# V-EC-18

## WATERPROOF END CAP

Used to fill the gap between the floor and carpet, hearths or against sliding doors.

Used with floors ranging from 6-8mm height.

*For concrete use appropriate Rawl Plugs (Not Included)*

*Glue with construction adhesive (do not glue floor)*

**Surface:** Wear resistant

**1**

Install the flooring leaving a 1-1/4" gap between the two floor surfaces for the end cap installation.

**2**

Measure and trim to fit.

**3**

Center the track between the flooring leaving a 1/4" spacing between the track and floor planks. Screw track to subfloor. (or glue down with construction adhesive).

**4**

Starting at one end, press the molding into the track inching along the length of the molding. It will NOT snap in all at once. You may also use a rubber mallet.